

### Sensor List

#### Buffer Allocation Failures

Monitors the Cisco switch for buffer allocation failures.

#### Buffer Create Failures


Monitors the numbers of buffer create failures caused by insufficient memory.

#### Buffer Element Misses

Monitors for an increase in the number of buffer element misses.

#### Cisco CPU

Monitors the CPU usage of the Cisco switch.



#### Device Memory

Monitors the percentage of free memory on the Cisco device.

#### Device Status

Monitors the status (available/not available) of the Cisco device.

#### Environmental Card Warnings

Monitors the environmental card test point warning flags.

#### Reload Status

Monitors for changes in the reason for the last reload of the System Bootstrap for the Cisco device.



[www.heroix.com](http://www.heroix.com)

#### Corporate Headquarters

120 Wells Avenue  
Newton, MA 02459  
tel: 800.229.6500 / 617.627.1550  
fax: 617.527.6132  
email: [info@heroix.com](mailto:info@heroix.com)

[Boston](#) ■ [New York](#) ■ [Atlanta](#) ■ [Chicago](#) ■ [Dallas](#) ■ [San Francisco](#)

Features and support may vary by platform. Heroix Corporation believes that the information in this document is accurate as of its publication date; such information is subject to change without notice. Heroix is not responsible for any inadvertent errors.

Heroix, the Heroix logo, and Heroix eQ are trademarks of Heroix Corporation. All other trademarks are property of their respective owners.

© 2003 Heroix Corporation. All rights reserved.